



BATTERY Replacement

How to replace battery on the IMPERA LINK™ Server



Notification in menu “Impera Link Server battery low”.



Battery Replacement within the period of **3 weeks**.




CONTACT YOUR SUPPORT

Ordering Batteries Part no.: IMP_BAT_254



When replacing the batteries, the Impera Link server must be connected to power supply!

In case of power supply loss all Jackpot data stored on the Impera Link server are lost.



⇒ Open battery compartment by removing **2 screws**.

⇒ Replace batteries. Make sure there is always a **battery inside!**

⇒ **Close** the battery compartment cover.



Notification in menu is cleared.



Please **CONTACT YOUR TECHNICAL SUPPORT TEAM** in case of any problems.



Scan to access all IMPERA LINK™ Server manuals.